

**IT3706**

**100%**

**Position**

**Print size (mm)**

**Print code (no of colors)**

1: Pouch PAD  
2: Pouch SCREEN

40x25  
60x35

P1(1)/C  
S1(1)/C



The transparent part of the pouch is sometimes on the front or on the back.  
Imprint will always be on the transparent part.